Standalone Rain Collector

GrowSphere™
Operating System

A device that gathers and measures the amount of rain in a certain area over a period of time. It provides local indication for a better decision making about your next irrigation.



/ Benefits & Features

- → Cost-efficient
- → Easy installation
- → Durable in any weather (UV resistant, frost & heat resistant)
- → Real-time monitoring
- → Better irrigation management
- → Operational cost reduction

/ Technical Specifications

Operating Specifications		
Resolution	0.25mm (0.01inch)	
Orifice	200cm² (31inch²)	
Accuracy	±5%	
Dimensions	165mm (6.5inch) x 255mm (10inch)	
Weight including angle brackets	380g (13.5oz)	

→ Wiring Diagram

- Digital input 2 wires
- · Connect the wires to the digital input terminals in any order

→ Installation

- 1. Assemble the two parts of the rain collector.
- 2. Fix the bird spikes on the funnel's circumference.
- 3. Place the leaf grid inside the funnel.
- 4. Use the metal bands to secure the device to the pole.
- 5. The unit should be mounted level on a rigid pole.
- 6. It should be hung in an open area, away from trees, to prevent leaves or debris from falling into the rain collector.

→ Care & Maintenance

- Remove any leaves or debris from the leaf grid as required.
- Make sure the drainage hole is always open and clean.
- If dirty, rinse the measurement unit with water and a cloth.

→ Kit Contents

- Rain collector
- Pole bracket
- 3-meter cable mounted to the sensor
- 2 x metal bands
- Bird spikes
- Leaf grid
- Calibration certificate
- Product sheet

→ Catalog Numbers

Description	Catalog Number
STANDALONE RAIN COLLECTOR	74320-000001

Technical Assets

